关于麦视

麦视（magicsee)是一家专注于虚拟现实穿戴式设备的公司，自2015年起，我们就致力于VR 3D头盔的研发。产品汇集优秀的工业设计，优良的人体工程学，精密的光学技术。融入反畸变技术，色彩补偿技术，影像算法技术，实现高沉浸感游戏，清晰震撼的全景场景体验。

目录

麦视M1 VR一体机
使用说明书

1、功能按键接口概览

1.1主机功能按键接口图示

电源键：长按（5秒）该键实现开机/关机，短按实现休眠/唤醒动作，长按（10秒）实现强制关机；
N键：Nubiru模式功能键；
音量+键：按下音量增加；
音量-键：按下音量减小；
向上键：按下向上选择；
向下键：按下向下选择；
向左键：按下向左选择；
向右键：按下向右选择；
● 键：按下确定；
�
↰ 键：按下返回主菜单；

1.2蓝牙遥控器功能按键图示

1.3 蓝牙遥控器连接及使用方法

将遥控器开关键拨到"ON"位置，蓝色LED灯快闪，打开设备>>蓝牙>>搜索设备，查找到"VR BOX"设备，点击配对连接即可使用，配对成功后LED灯熄灭。

蓝牙遥控器充电:

将手柄接入5V电源进行充电(如PC设备或手机的电源适配器),
充电过程中,手柄的充电指示灯为红色并保持长亮,电量饱和后
LED熄灭；

2、用户须知

2.1 注意事项
请不要在禁止使用无线设备的地方使用一体机；
请使用原装的配件，如电源适配器；
请保持一体机干燥；
请用户在第一次使用一体机前先预览操作说明书；
如遇到一体机卡死等软件问题，可按住开机键10秒钟强制关机，过10秒钟后，再按开机键开启一体机。

2.2 充电
请使用原装的电源适配器直接充电；
关机状态下插上电源充电，一体机会启动；
充电时，面壳上蓝色灯条亮起；
充电时，尽量保持一体机休眠，以便高效充电；
电量低4%时，请及时充电，如耗光电量再充电，请保持充电10分钟后，才能启动一体机。

2.3 一体机连接电脑
用USB线将一体机与电脑连接上，在计算机中找到一体机的存储盘，就可以自由传输数据。

2.4 插入TF卡
将TF卡对准TF卡槽，TF卡金属接口面朝头带方向插进去。

2.5 接入耳机
将3.5mm标准耳机接头插入一体机，当有音频输出时，即可听见声音。

3、主机基本操作

3.1 主页面

主页面包括本地、在线影院、全景OL、唱吧VR、图片、工具，电量显示、时间显示、接入设备显示、无线网络状态。

3.1.1 本地

本地选项中包括本地播放器、PPTV、唱吧VR、全景OL、设置、应用市场、文件管理、浏览器等部分。

※本地播放器

选择视频：使用配对的遥控器或按键选择需要播放的视频；

播放视频：选定视频后，点确认键播放视频；

选择播放方式：可以选择2D播放、3D播放、全景播放；

播放进度条：有低头动作时进度条出现，拖动可以选择播放进度；

暂停播放：点击即暂停播放视频；

循环播放：点击可实现视频循环播放；

音量调节：点击进度条下方的喇叭图标可调节音量；

亮度调节：点击进度条下方的小太阳图标可调节亮度；

播放菜单：可以进行软硬解码切换及播放方式选择；

返回按键：点击返回播放视频列表。

※PPTV

进入应用后有精选、3D、2D等内容分类，可以根据需要选择播放。

※唱吧VR

进入应用后有3D回放、3D直播、2D直播等分类，可以根据需要选择播放。

※全景OL

进入应用后有风景、创意、美女、热播等分类，可以根据需要选择播放。

※设置

设置选项中包含无线网络、蓝牙、通用、系统、账户等部分。

※无线网络

扫描可用的无线网络，输入对应的无线网络密码即可连接网络。选择对应的无线网络可以断开连接和取消已保存的密码。

※蓝牙

打开蓝牙后，自动搜索蓝牙设备，列表会显示搜索出来的蓝牙设备名称。用户可以根据需要来选择连接蓝牙设备。
注意：出现已匹配设备无法连接的情况，先取消配对，再次尝试搜索连接设备。

※通用

通过通用选项，可以调节屏幕亮度、音量大小、选择语言、选择主题、更

改时区。

※系统

进入系统选项，有更新系统、恢复出厂设置、关于设备三个选项系统更新

有以下方式：

a、在线更新，如果有可用的新版本系统可以自己下载并更新。
b、用户将下载好的固件放到本地，手动选择更新。
--关于设备：用户可以查看到系统版本，一体机硬件/软件参数。

※ 账户
填入注册好的Nibiru账号就可以登录，如无账户可登录www.inibiru.com注册。

※ 高清输入
显示观看HDMI输入的视频，体验PC或游戏主机输出3D游戏。

※ 浏览器
可以通过浏览器进行上网等操作。

※应用市场

　　用户可以通过WIFI在应用市场中下载安装游戏和普通应用程序。

※ 文件管理器
进入后可选择分类浏览、内部存储、SD卡。可以查看内部存储、SD卡等容量信息，并可根据需要打开、删除文件。

3.1.2 在线影院

　　进入应用后有精选、3D、2D等内容分类，可以根据需要选择播放。

3.1.3全景OL
进入应用后有风景、创意、美女、热播等分类，可以根据需要选择播放。

3.1.4 唱吧VR
进入应用后有3D回放、3D直播、2D直播等分类，可以根据需要选择播放。

3.1.5图片
进入应用后有照片墙、全景图片，可以浏览对应格式的图片。
注意：全景图片须存放在VR-media文件夹下。

3.1.6工具

　　进入后有设置、本地播放、市场、HDMI、文件管理五个部分内容。

包装清单：

一体机一台

蓝牙遥控器一个

电源适配器一个

USB2.0数据线一条

头戴一条

HDMI线一条

操作说明书一本（带保修卡）

QC PASS标签

保修卡

保修说明：

1、欢迎您选用本公司VR一体机，若该产品因质量问题而引起的故障或损坏，请及时送回指定维修点或经销处。自购买之日起7天内包退，15天内包换，1年内有限保修。

2、若是自行拆卸或使用不当等人为原因而引起的故障或损坏，不在保修范围内。

3、请妥善保存此卡，凭卡保修，不得有任何涂改

用户姓名	
联系电话	
用户地址	
产品型号	
购买日期	
发票号码	
销售单位名称	
销售单位地址	
邮政编码	

ABOUT MAGICSEE

"Magicsee" is a professional company that is focus on virtual reality headset equipment. since 2015, we are committed to the development of 3D VR headset. Guides excellent industrial design, excellent ergonomics, precision optical technology. Into the anti-distortion technology, color compensation technology, imaging algorithm technology, high immersive games, crisp, powerful panoramic scene experience.

Directory

Magicsee M1
User Manual

1.1function keys Interface overview

1.2Main Interface function

Power

Headphone jack

Video in

USB Charging port

Charging LED

TF Card Reader

Left

OK

VOL +

Video Mode

VOL −

HD   USB

Up

Right

Down

Return

Power key: Long press (5 seconds) the key to achieve power on / off, short press to achieve the sleep / wake-up action,longer press (10 seconds) to forcibly power off ;

N key: the video mode setting key , it can choose single dual setting, VR panorama mode setting ;

Volume + key: Press the volume up ;

Volume - key: press volume down ;

Up : Press to select up ;

Down : press to select down ;

LEFT: Press to select left ;

RIGHT: Press to select right ;

● key:to Press OK ;

↰Key: Press back to main menu;

1.2 Bluetooth controller keys function

360°
Control Rocker

Mode

Return

OK

Power

A   B

C   D

USB Charger

1.3 How to connect the bluetooth controller

Move to the "on " button on the side part of the controller;The LED will flashing. Then go to open the device>>Bluetooth>>Searching device, find "VR BOX" to pairing, And LED of controller is extinguish when connected.

2.NOTICE

2.1 Precautions

Please use original accessories such as the power adapter；

Please keep the machine drying；

Please preview the user manual before using the machine；

If suddenly the machine stopped work, press and hold the power button for 10 seconds to force shutdown, over 10 seconds, then power on again。

2.2 Charging

Please use the original adapter for charging；

Charging when the machine is power off, the machine will start work；

When charging, the surface show blue light；

When charging, try to keep the machine sleep, in order to efficiently charge；

When the battery is lower than 4%, please charge now; such as run out of battery,when recharging, keep charging for 10 minutes, then to start again。

2.3 How to connected to the computer

Connected to the computer by USB cable, then to find the storage disk from computer, you can transfer data freely.

2.4 insert TF card

Put the TF card to the TF slot,then the device will work.

2.5 Headphones

The 3.5mm standard headphone connector into the machine, when there is an audio output, you can hear the sound.

3.Main Operations

3.1 Home Menu

Home Menu showing: Local setting, Live cinema,360°Online, KTV VR, Photos,Tools, battery status, Time display, access device display, wireless network status.

3.1.1 Local app

Local options including Media player, PPTV, VR Live, 360° Online, settings, App Store, File Explorer , browser and HDMI in.

※Media Player

Select the video: Using paired remote or button to select the video you want to play;
Play Video: After selecting the video, click the Enter key to play the video;
Select the playing mode: You can choose to 2D playing, 3D playing, 360° panoramic play;
Playing progress bar:it will be showing the progress bar when lower your head, select the play progress;
Pause Play: Click-pause a video;
Loop Playback: Click on the video loop can be realized;
Volume control: By clicking "the speaker" button below the progress bar to adjust the volume;
Brightness adjustment: Click " the little sun" Button below the progress bar to adjust the brightness;
Playing menu: you can switch the hardware and software decoding and playing mode selection;
Back button: Return to play the video list.

※PPTV

After entering the applications, there are 3D, 2D and other content categories, you can play as your request.

※VR Live

After entering the application, have 3D playback, 3D TV, 2D broadcast, etc. you can play as your request

※360 Online

After entering the application, there are scenery view, creativity, beauty, hit, etc. and you can play as your request.

※Settings

Setting Options contain Wi-Fi, Bluetooth, universal, system, account ect

※WIFI

Scan the available wifi and input the password to contact the internet. Select the corresponding wifi to disconnect the internet and forget the password.

※Bluetooth

Turn on the Bluetooth and search for bluetooth devices automatically , the list shows that bluetooth device name you search out. Users can choose the bluetooth device to connect as need.
Note: when you can't connect the matched device, please cancel the pairing and try to search the device to connect again.

Normal

To adjust the screen brightness, volume, choose language, theme and change the time zone with General option.

※System

There are system update, factory reset and about device in the System option.
a) Online update, if there is a new version system available can be downloaded and updated itself.
b) User can down the Firmware to the local file and update manually.

About device, user can check the system version, hardware / software parameters of the all in one VR

.

Account
Input the registered Nibiru account can login in, please visit the website www.inibiru.com to register if no account.

HDMI input
Display and watch the HDMI video, experience PC or game machine to output the 3d games.

Browser
Surfing the internet via Browser.

App Store
User can connect the Wifi to download and install games and some applications from the AppStore .

File Manager
There are classification, internal memory, SD card in the File Manager. You can view the capacity information of internal memory and SD card, and can open and cancel the file as need.

Cinema Online
There are selection, 3D, 2D ect of the content for selection, you can play as need.

360° Online
There are scenery, originality, beauty, hot ect for selection, you can play as need.

Live VR
There are 3D playbacks, 3D live, 2D live ect for selection, you can play as need.

Photos
There are photo wall, panoramic Image and you can view the corresponding format Image.
Note: Panoramic Image should be saved in the VR-media file only.

Tool
There are setting, local play, market, HDMI IN and file management five parts for Tool option.

packing list:
1X M1
1X Bluetooth game controller
1X Power adapter
1X USB2.0 cable
1X head-strap
1X HDMI cable
1X User manual